

## Insert Car Seat Cover Fitting Instructions:



### Remove separate Headrest.

The method of removal varies from manufacturer to manufacturer. The image shown has one single button and the headrest is easily removed. Some have a secondary Button on the other side which is not obvious with a quick glance. Consult your operators manual or car dealership for more information if you are unclear about your vehicle.

### Place top of cover over the top of the seat.

The size adaptable tape on top of the seat cover should be aligned with the post hole for the posts to be slipped back into place.



### Push 1" elastic Tapes through the back of the Seat.

The tapes are designed to be pushed through the back of the seat and eventually tied to loops of elastic coming from under the front of the seat. The design of seats is very different from one model of vehicle to the next. Some brands have a flap on the rear of the seat that needs to be released to gain easy access to these straps for tying off.

Again it may be easier to consult your operators manual or car dealership for more information if you are unclear about your vehicle

### Join the front loop under the seat to the tape with a solid stretch and slip knot in the tape for easy removal.

Pass the loop under the seat from the front (often a 2 person job) .

Pass the tape through the loop and pull firmly.

Tie a slip knot in the tape to secure the seat cover.



[www.goodwool.com.au](http://www.goodwool.com.au)

Good Wool Store Pty Ltd

Berry NSW Australia

Copyright January 2019